



## Fuse Replacement for PPC-3 Monitor


- Remove (4) Screws on bottom of case and remove metal enclosure from the case.


- Remove (3) Screws From Blank Side

Loosen and Remove the switch knobs using a .05 Allen Wrench.


Remove (4) screws from output side


- Lift TOP cover upwards from the bottom and slide forward to remove from the bottom half of the enclosure.


- Circuit Board In bottom half of enclosure.

Replace Fuse

Buss AGC 250V 1/4A


- Reassemble case.