


INSTALLATION & OPERATION

V SERIES LOAD CONTROLS AND POWER CELLS FOR VARIABLE FREQUENCY AND DIRECT CURRENT POWER



Power Cells Sense Motor Power From Variable Frequency
And DC Drives — V Series Load Controls Use This Signal
To:

- Adjust Machines and Processes
- Signal Beginning or End of Process
- Detect Trouble
- Protect Machines and Processes

 **LOAD CONTROLS
INCORPORATED**

53 TECHNOLOGY PARK ROAD
STURBRIDGE, MA 01566
TEL. 508-347-2606
FAX 508-347-2064
www.loadcontrols.com

